



ALARM STATUS	FAULT
● (red) ● (grey) ● (grey) ● (yellow)	BLOCKED
● (red) ● (grey) ● (yellow) ● (grey)	LOW VOLTAGE
● (red) ● (grey) ● (yellow) ● (grey)	ELECTRICAL ERROR

	OPERATING PANEL	CONTROL MODE	
0	● (green) ● (grey) ● (grey) ● (grey) ● (grey)	PROPORTIONAL PRESSURE AUTO ADAPT	▶
1	● (grey) ● (green) ● (grey) ● (grey) ● (grey)	CONSTANT PRESSURE AUTO ADAPT	▶
2	● (green) ● (grey) ● (yellow) ● (grey) ● (grey)	PROPORTIONAL PRESSURE 1	▶
3	● (green) ● (grey) ● (yellow) ● (yellow) ● (grey)	PROPORTIONAL PRESSURE 2	▶
4	● (green) ● (grey) ● (yellow) ● (yellow) ● (yellow)	PROPORTIONAL PRESSURE 3 - MAX	▶
5	● (grey) ● (green) ● (yellow) ● (grey) ● (grey)	CONSTANT PRESSURE 1	▶
6	● (grey) ● (green) ● (yellow) ● (yellow) ● (grey)	CONSTANT PRESSURE 2	▶
7	● (grey) ● (green) ● (yellow) ● (yellow) ● (yellow)	CONSTANT PRESSURE 3 - MAX	▶
8	● (grey) ● (grey) ● (yellow) ● (grey) ● (grey)	CONSTANT CURVE 1	▶
9	● (grey) ● (grey) ● (yellow) ● (yellow) ● (grey)	CONSTANT CURVE 2	▶
10	● (grey) ● (grey) ● (yellow) ● (yellow) ● (yellow)	CONSTANT CURVE 3 - MAX	▶